

Choosing the Right Hinge and the Right Number of Hinges

If the information you need is not on this chart, consult GLOBE Manufacturing.

To obtain the best performance from SOSS Invisible Hinges, it is recommended that the largest hinge model be used for the material thickness of the door.

Every door should be provided with at least one hinge for every 30 inches in height or portion thereof; however, more hinges may be required per chart below.

Door Width

in Inches and Millimeters

100

200

300

For example, a 90" door needs three hinges and a 91" door needs four.

DIRECTIONS

Door Weight

225

180

in Pounds and Kilograms

500

400


200

60

After determining the weight and width of the door, draw a straight line through the door width and weight to line "A", as indicated in the example.

Continue with a horizontal line sideways from the point of intersection with line "A" until the door thickness is reached. Use the number of hinges and the model number indicated on this line.

To use this chart as a working guide, we suggest that you print this page.



2

8 2

Hinge Number

NOTE: For Fire-Rated Hinges, use formulas described on page 49.

EXAMPLE

A wood door 30" wide, 200 lbs., with a thickness of 134" will require four #218 SOSS Invisible Hinges. The red line shows how the sizing and selection were determined from the hinge sizing chart

The hinge sizing chart above has been developed to assist you in determining the correct size and number of hinges for your installation.

NOTE: For doors that exceed size/weight on this chart, consider using the Hercules hinges. Contact us for more information.